

ATTENTION

Microsoft® Windows® 98 SE Users

If you are connecting your DVR-SK12D DVD Writer to a Windows 98 computer via the USB2 port, you must first install the driver available from the Pioneer website (www.pioneerelectronics.com) under Business Products.

Please review the README file included with the download before attempting to install the driver.

DVR-SK12D

ATTENTION

Microsoft® Windows® 98 SE Users

If you are connecting your DVR-SK12D DVD Writer to a Windows 98 computer via the USB2 port, you must first install the driver available from the Pioneer website (www.pioneerelectronics.com) under Business Products.

Please review the README file included with the download before attempting to install the driver.

DVR-SK12D

ATTENTION

Microsoft® Windows® 98 SE Users

If you are connecting your DVR-SK12D DVD Writer to a Windows 98 computer via the USB2 port, you must first install the driver available from the Pioneer website (www.pioneerelectronics.com) under Business Products.

Please review the README file included with the download before attempting to install the driver.

DVR-SK12D

ATTENTION

Microsoft® Windows® 98 SE Users

If you are connecting your DVR-SK12D DVD Writer to a Windows 98 computer via the USB2 port, you must first install the driver available from the Pioneer website (www.pioneerelectronics.com) under Business Products.

Please review the README file included with the download before attempting to install the driver.

DVR-SK12D